



Liver Cancer miRNA Profiling Plate Assay Kit II

Catalog Number MA-0114

(For Research Use Only)

Introduction

miRNAs have been implicated in regulating various biological processes such as cell death and cell proliferation. They can act as oncogenes and tumor suppressor genes, playing a crucial role in tumorigenesis. The change in the expression level of miRNAs is associated with dysfunction of their corresponding protein-coding gene targets, many of which are involved in initiation and progression of cancer. Signosis' Liver Cancer miRNA Plate Assay Kit II can quantitatively profile the expression of seven well-known cancer related miRNAs: miR-125a, miR-141, miR-199a, miR-200b, miR-221, miR-224, and miR-320. U6 is included for normalization.

Principle of the assay

Signosis' proprietary miRNA plate array utilizes plate-based detection. In the assay, one miRNA molecule is flanked by a capture oligo and a biotinylated detection oligo through two bridge oligos. One of the bridge oligos is partially hybridized with the miRNA molecule and the capture oligo and another one with the miRNA and the detection oligo. The hybrid is captured onto the plate through hybridization with an immobilized oligo and detected by a streptavidin-HRP conjugate and chemiluminescent substrate. This hybrid structure is sensitive to the sequence of the miRNA molecule. One nucleotide difference can prevent the formation of the hybrid and therefore miRNA isoform can be differentiated, which normally is hard to do with a Northern blot. In addition, the sensitivity of this assay is higher than a miRNA Northern blot assay.

Materials provided with the kit

- One 96-well white plate (4°C)
- Streptavidin-HRP conjugate (4°C)
- Plate Hybridization buffer (RT)
- 5X Plate Hybridization wash buffer (RT)
- Blocking buffer (4°C)
- 5X Detection wash buffer (RT)
- Substrate A (4°C)
- Substrate B (4°C)
- Substrate dilution buffer (4°C)
- 8 different miRNA oligo mixes

Material required but not provided

- ddH₂O (RNAase free)
- Hybridization incubator
- Shaker
- Plate reader for chemiluminescent detection

Reagent preparation before starting experiment

- Warm up Plate Hybridization buffer, 5x Plate Hybridization wash buffer, Blocking buffer, and 5X Detection wash buffer at 42°C before use.
- Dilute 30ml of 5X Plate Hybridization wash buffer with 120ml of ddH₂O. Warm up to 42°C before use.
- Dilute 40ml of 5X Detection wash buffer with 160ml of ddH₂O. Warm up to 42°C before use.
- Dilute streptavidin-HRP with Blocking buffer 500 times before use at Step 7.

Assay procedure

1. Warm up the plate to room temperature and arrange the appropriate number of the wells of the plate based on your experiment by removing the foil sealing film with a blade. Keep the unused wells sealed.

Dilute each oligo mix 30 times with RNAase free ddH₂O

Mix the following items in one well.

2µl -5µl RNA (0.2µg-2µg)
100µl Plate Hybridization buffer
4µl diluted oligo mix
4µl Biotin Detection Oligo

2. Seal the wells with foil film securely and incubate the plate at 42°C overnight. Ensure the numbers and letters on the plate are clearly visible from under the foil seal by pressing the foil down on every single experimental well.
3. Remove the foil sealing film with a blade to expose the experimental wells. Keep the unused wells sealed for future usage.
4. Invert the plate over an appropriate container and expel the contents forcibly. Then, wash the plate by adding 200µl of warmed 1X Plate Hybridization wash buffer. Completely remove the liquid at each wash by firmly tapping the plate against clean paper towels. Repeat the washing process two times for a total of three washes.
5. Add 200µl of Blocking buffer and incubate for 15 minutes at room temperature with gentle shaking.
6. Invert the plate over an appropriate container to remove the Blocking buffer.
7. Add 100µl of diluted streptavidin-HRP conjugate to each well and incubate for 30 minutes at room temperature with gentle shaking.
8. Invert the plate over an appropriate container and expel the contents forcibly. Wash the plate with 200µl 1X Detection wash buffer and allow the buffer to incubate in the wells for 5 minutes. Completely remove the liquid at each wash by firmly tapping the plate against clean paper towels. Repeat this step two times for a total of three washes.
9. Prepare the substrate solution:
For the whole plate:
1ml Substrate A
1ml Substrate B
8ml Substrate dilution buffer
10. Add 95µl substrate solution to each well and incubate for 1 minute.
11. Place the plate in a luminometer and read. Set integration time to 1 second with no filter position. For the best results, read the plate within 5-20 minutes.